

 **This page is not fully translated, yet. Please help completing the translation.**
(remove this paragraph once the translation is finished)

Module „CLT-Plate 1D - Internal forces“



Input data

The input is divided into:

- definitions of the cross section
- specifications concerning structural fire design
- internal forces according to the theory (of 1st or 2nd order) on which the calculations are based on
- design factors
- specifications concerning stability

Cross section

The input is the same as for the module [Module "CLT-Plate 1D - Continuous beam"](#).

[Show description](#)

Fire

The input is the same as for the module [Module „CLT-Plate 1D - Continuous beam“](#).

[Show description](#)

Type of calculation, internal forces, design factors and specifications concerning stability

The internal forces and the underlying type of calculation are defined in the tab „Internal forces, stresses and utilisation ratios“. Additionally, the design values are specified here.

If the internal forces result from a calculation based on a first order analysis a substitute buckling length has to be stated in case of a negative normal force ("problem of stability"). Based on this buckling length and the respective cross section the required buckling factor k_c needed for the verification is calculated automatically.



Results and output

Cross section values

The output is the same as for the module [Module „CLT-Plate 1D - Continuous beam“](#).

[Show description](#)

Summary of the results

The stress distributions and the governing utilisation ratios are shown in the tab "Internal forces, stresses and utilisation ratios".



Detailed results

Stresses and utilisation ratios of the single layers are shown when clicking on the "Details" button.



From:
<https://www.ihbv.at/wiki/> - **IHBV Wiki**

Permanent link:
https://www.ihbv.at/wiki/doku.php?id=en:clt:hotspot:software:cltdesigner:manual:modul_plate1d_internalforces&rev=1510829638

Last update: **2019/02/21 10:31**
Printed on 2025/09/19 15:59